
HOW WE USE ENERGY IN OUR HOME


Average Monthly Appliance Use



LOOK OUT FOR THESE **ENERGY EATERS!**

There are a handful of appliances and devices that are particularly power-hungry. Think twice about equipment including:

- Space heater
- Hot tub
- Fish tank or aquarium
- Halogen lamps
- Old, extra refrigerators and freezers
- Home office equipment
- Pumps for well, pool, ponds/waterfalls and septic systems



Outsmart Energy Waste and Lower Your Electric Bill

WHERE TO START

• Make sure the "shell" of your home is tight. Check doors and windows for air leaks, examine caulking and ensure adequate insulation.

 Adopt habits like the ones here that will help you waste less energy and lower your electric bill. Start with heating, cooling and hot water use because changes in these areas often make the biggest difference.

Outsmart Energy Waste and Lower Your Electric Bill

Heating

- Lower the temperature in your home. Set the thermostat as low as it's comfortable. Try for 68 degrees or lower during the cold months.
- If you heat with a furnace or heat pump, turn the thermostat down at night or when you aren't home. Consider a programmable thermostat to make the changes automatic.
- Clean or change furnace and air conditioning filters regularly. Monthly is recommended.
- Close your curtains at night to keep heat inside and open them during the day to allow sun to help warm your home.
- If you have a fireplace, keep the damper closed when it's not being used.
- During winter, keep windows and exterior doors closed to keep heat inside. In the summer, open windows only when it's cooler outside than the temperature inside your home.
- Keep your baseboard and wall heaters clean. Arrange furniture and window coverings so they don't block airflow from registers or heaters.
- Seal seams and openings from the inside to outside of your home with caulk, weather-stripping or spray insulation to prevent air from leaking in or out.

Lighting

- Replace traditional incandescent light bulbs with LED bulbs. Compare lumens to make sure the lower wattage bulbs will provide the same amount of light.
- Use timers or sensors on security lights so they shine only when needed.
- Turn off lights in rooms not in use or when natural light is enough.
- Dust your light bulbs and fixture covers to get the most light out of your lamps and fixtures.
- Paint or decorate in light colors to reflect more light in the room.
- Add dimmer switches and use the bulb's full brightness only when needed.

Water Heating and Washing

- Set your water heater thermostat between 120 and 130 degrees.
- Wash only full loads in your clothes washer and dishwasher.
- Use the lowest practical level of water for anything less than a full load.
- Try a cold water detergent and wash clothes in cold water. Always use a cold water rinse.
- On your dishwasher, use the "air dry" setting and other power-saving features.
- Consider EnergyStar[®] models when replacing appliances. They use less water and energy and will lower your electric bill for the life of the appliance.
- Fix leaking or dripping faucets.
- Install water-saving showerheads that use 2.5 gallons per minute or less.
- When away from home for three days or more, turn off the circuit breaker to your electric water heater (except in freezing weather).
- Insulate all pipes in unheated areas with foam pipe wraps. Don't forget to wrap the hot water pipe leaving your water heater.

Cooking

- Use your microwave instead of your range oven to warm food. Smaller appliances like toaster ovens and crock-pots use less energy, too.
- Choose flat-bottom pans to maximize contact with stove burners and use tight-fitting lids to keep steam in the pan.
- When heating water, use only as much as you need to cut down on cooking time. • Try to match the pan size to the burner size. Using too small a pan on a large burner can waste energy.
- Cook more than one item at a time when you use your oven.
- Use a timer to limit the number of times you open the oven door during baking.
- With glass or ceramic cookware, decrease the oven temperature by 25 degrees.
- Don't use your oven to heat the room.

Refrigerating and Freezing

- Keep your refrigerator at 37 to 40 degrees and your freezer at 0-5 degrees.
- Freezers are more efficient when kept full milk jugs filled part way with water can be used to fill space.
- Defrost your freezer when ice or frost gets one-quarter inch thick or more.
- Vacuum or dust your freezer/refrigerator coils at least every six months. *Coils are on the back of or underneath the appliance.*
- Check your refrigerator and freezer door gaskets periodically for signs of deterioration and replace them when necessary.
- Know what you're looking for before opening the refrigerator or freezer door and mark items for quick identification.
- When purchasing new major appliances, compare energy costs and consider EnergyStar[®] models.

Clothes Drvers

- Plan laundry with drying in mind and separate lightweight items, which take less time to dry, from heavy ones.
- Don't overdry clothes and line dry whenever possible.
- Keep the dryer vent and lint filter clean.
- Check to make sure the moist air is exiting your home.

Preventing Air Leaks

Air leaks waste energy and make your home less comfortable. Checking for air *leaks in your home can help keep your electric bills down year round.*

- Replace broken or cracked windows.
- Seal gaps around windows and doors.
- Adjust weather-stripping so it fits snuggly.
- Add insulation, caulking, foam or other sealing materials to block air flow.
- Check attic and crawl space hatches.
- Install glass doors on fireplaces and close the damper when not in use (48 hours after the last fire).
- Check the "R" value of your insulation and add more if needed. Attic or ceiling insulation should be at least R-38 and floor insulation should be between R-19 and R-30.



Remember! If you're not using it, turn it off and unplug. Many electronics like chargers (phone, laptop, etc.) continue to use energy as long as they're plugged in. And appliances in standby mode use electricity as well. Try a smart strip to cut off power at the source when not in use, and reduce wasted energy!







KNOWLEDGE IS POWER!

Read your electric meter before you leave for vacation and again when you return home. Then you'll know how much energy your home uses when it's empty. To read your meter, write down the number on each dial. If the pointer is between numbers. record the smaller number.

Bon Voyage! Tips to cut waste when you're away

Before an extended getaway, make sure your home is ready. Making a few changes before you leave can keep energy costs down and also make your home more safe.

- Turn gas water heater down or turn off electric water heater at the breaker.
- In the winter, set your thermostat at 50-55 degrees (but no lower). It'll be chilly when you get home but not so cold that pipes will freeze.
- Unplug portable heaters as well as your clothes washer and dryer. Insulate pipes to keep them from freezing.
- Protect the food in your freezer by asking a neighbor to check on it periodically, especially if there's an outage, to make sure it's back on and working properly.
- Unplug all appliances, including the toaster, coffee pot, iron and microwave oven.
- Unplug electronics like TVs, DVD players and computers. Many of these devices continue to draw power even when off. If left on, it's a good idea to use a surge protector.
- Timers can be used to turn lights and other small items on and off when you're not home as a deterrent to potential burglars.
- Turn off all the lights except those attached to a timer.
- Let Clark Public Utilities and other service providers know if you'll be gone for an extended period of time to make arrangements for bills you may not be home to receive.
- Put a hold on mail and newspaper deliveries.



Call an energy counselor at 360-992-3355

Email ecod@clarkpud.com

Find us online!



