

- 1. APPROVED PRESSURE VALVE BREAKER ASSEMBLY MUST BE INSTALLED VERTICALLY, 12" MIN TO 5' MAX ABOVE THE HIGHEST POINT OF USE AND ALL DOWNSTREAM PIPING.
- DESIGNED FOR BACK SIPHONAGE ONLY, NOT BACK PRESSURE.
- 3. DISINFECT, PRESSURE TEST AND THOROUGHLY FLUSH LINES PRIOR TO INSTALLATION OF BACKFLOW PREVENTER.
- 4. IF A PVBA IS INSTALLED INDOORS, CONSIDERATION MUST BE GIVEN TO WATER LEAKAGE IF THE BACKFLOW PREVENTER FAILS (EXCESSIVE WATER SPILLAGE).
- 5. THE BACKFLOW ASSEMBLY SHALL BE PROTECTED FROM FREEZING AND FLOODING.
- THE BACKFLOW ASSEMBLY SHALL BE A STATE APPROVED MODEL.
- 7. A PLUMBING PERMIT IS REQ'D. PLEASE CONTACT YOUR LOCAL PLUMBING PERMIT CENTER.
- 8. MUST BE TESTED AFTER INSTALLATION AND YEARLY THEREAFTER BY A WASHINGTON STATE CERTIFIED BACKFLOW ASSEMBLY TESTER. TEST RESULTS SHALL BE SENT TO CLARK PUBLIC UTILITIES WATER SERVICES.

REVISED JANUARY 2026

TILE NAME

STANDARD PVBA

(PRESSURE VACUUM BREAKER ASSEMBLY)

2" & SMALLER

SHEET 1 OF 1 STANDARD DETAILS

